

**“Hey Godfrey,  
Something is wrong  
I hooked up the HubBub to my guitar and rig and it is not working”**

**While it is always possible that there could be a defect in my wiring of the pedal, with over 410 pedals made in over a 13 year period, none have ever failed or been return for not working.**

**Nevertheless, I do occasionally get an email or phone call with the above quoted statement. In each and every case, the problem is this:**

**The OBEL jack on the guitar is wired backwards.**

The HubBub requires that the OBEL jack be wired Tip to SEND and Ring to RETURN as per the wiring diagram on dozin.com of Doug Irwins Tiger guitar.

**The fix is simple. Just open the OBEL jack on the guitar and reverse the 2 leads. Do not change the 3<sup>rd</sup> ground wire. If you are not up to doing this yourself, Any guitar repair guy can do it.**

Once that is accomplished, your rig with The HubBub will work perfectly.

FYI- Do not try to use a “Y” cable with the HubBub. The HubBub eliminates the need for it. You must use a stereo cable with a TRS (Tip, Ring, Sleeve) jack on both ends for the OBEL jack